

Please go to www.quoizel.com for product cleaning tips. Go to the **Care + Maintenance** selection.

Tools Required: None.

Light Source: (2) A19 Medium Base Bulbs 100W Maximum, bulbs not included.

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact your original place of purchase.

⚠ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

⚠ Care of Tiffany Style Shade

A new tiffany lamp shade has an oil film applied to the shade that protects the tiffany shade from scratches during shipment. If the oil applied is too heavy you can remove the excess oil film with a paper towel. Gently wipe away the excess oil.

For general cleaning of tiffany shades use a gentle lemon oil-based furniture polish applied to a soft cloth and wipe gently.

If a white powder appears on the soldered joints of the tiffany shade this is a normal oxidation process. Use a small amount of lemon oil or mineral oil applied directly to oxidized areas and the soldered area will return to like new.

- A. Thread the Socket Assembly, the Tubes w/ Nipple, the Tube and the Base together as shown. Hand tighten until snug. Pull the cord from the Base as you assemble them together to remove the excess cord between parts.
- B. Thread the Stem onto the hex coupling on the top center of the Socket Assembly. Hand tighten until snug.
- C. Place the Spacer Tube and the Check Ring over the top end of the Stem and secure with the Small Knurled Nut. Hand tighten until snug.
- D. Thread the Big Knurled Nut onto the top end of the Stem and adjust it to proper location for rest components. Place the Flat Washer and the Shade over the top end of the Stem as shown. Secure with the Finial and hand tighten until snug.
- E. Insert bulbs onto sockets and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!

